


Chlamydia/Gonorrhoea - Urine

About your Test

- Your health professional has requested this test to check for Chlamydia trachomatis and/or Neisseria gonorrhoeae.
- This test is done by a urine sample. Make sure you have not urinated for at least 1 hour prior to specimen collection.
- Do **not** cleanse the area around the urethra prior to collection of the sample.

Test Procedure

1. Upon urinating collect the first 20 to 30 mL into the specimen container. As a guide, 20mL is approximately the DOB line on the container label.




2. Open the Urine collection pack and remove both the pipette and tube. Remove the lid from the tube. Avoid touching or piercing the silver foil in the lid.

TUBE CONTAINS LIQUID, DO NOT TIP OUT

If fluid is spilled, request a new kit and start again.

3. Using the pipette, squeeze the bulb at the top firmly, place the tip into the previously collected urine, and draw urine up to the top line by releasing pressure on the bulb.


4. Transfer urine into the tube so the liquid level is between the black fill lines.



Recap the tube firmly.

5. Label the tube clearly with your full name and date of birth. Discard remaining urine, packaging and pipette – keeping just the filled tube.

6. Return labelled tube and form in the provided biohazard bag as soon as possible to the laboratory or to one of our collection centres.



Reminder: Have you labelled the tube?